

System Type	Equation
Split system air conditioner < 45,000 Btu/h	SEER = SEER2 X 1.049
	EER = EER2 X 1.043
Split system air conditioner ≥ 45,000 Btu/h	SEER = SEER2 X 1.051
	EER = EER2 X 1.045
Split system heat pump	SEER = SEER2 X 1.049
	HSPF = HSPF2 X 1.173
Packaged air conditioner and heat pump	SEER = SEER2 X 1.045
	EER = EER2 X 1.038
	HSPF = HSPF2 X 1.176
Space constrained air conditioner	SEER = SEER2 X 1.026
Space constrained heat pump	SEER = SEER2 X 1.008
	HSPF = HSPF2 X 1.175
Small duct high velocity system	SEER = SEER2 X 1.000
	HSPF = HSPF2 X 1.180

*Table 1: Equations to Convert Respective Ratings for the 2019 Energy Code
Source: California Energy Commission*